


SERVICE INFORMATION 		R10.00 2024-001 Linking Scanreco remote with display	
		Written By	Jorge Borrayo
Page Count	(1) Page	Department	Service
02 02 2024	Linking Scanreco remote with display MINI and MAXI – ID download		

Step	Procedure
1	Remove battery from old transmitter. Connect tether cable between receiver and new transmitter.
2	Every function in neutral position. Volume control at MAXIMUM. Release E-Stop
3	Cycle power on receiver. Toggle switch from OFF (Center) to Remote (Towards front) position. Next Step must be done within 45 seconds of step 3
4	Press and hold Power Button. Power ON LED illuminates solid RED and Buzzer in transmitter beeps once. PCU ID is now being sent to receiver When the display read Po Id release the power button
5	The transmitter will beep in quick succession to confirm programming is completed and will turn off by itself
6	Tether cable connected, turn the transmitter on. Display will show: “Loading Icons”, when it finish will shut down.
7	Disconnect the tether cable. Install the battery and test the transmitter